



## 2015+ Ford Mustang Catch Can

**Install time:** 30 to 45 minutes

### **Tools:**

- Socket driver
- Flat head screwdriver
- 10mm socket
- 13mm socket
- Trim tool (recommended)

### **Instructions:**

1. Remove plastic shroud covering radiator (8 plastic clips). Tip: Use trim removal tool or flat head screw driver. (Fig 1)
2. After shroud is removed, locate passenger side radiator. Remove (2) 10mm bolts and rotate mount. (Fig 2-3)
3. Pre-assemble mounting bracket to the back of catch can using supplied hardware and 13mm socket. (Fig 4)
4. Install catch can in vehicle, place mounting bracket below radiator mount and install (2) bolts using 10mm socket. (Fig 5)
5. Remove OEM PCV hose. Slide gray tab and pull away from mounting location. (Fig 6)
6. Using supplied hose provided in kit, install to catch can and OEM locations. PCV line will mount to the lower hose barb. Re-install plastic shroud and installation is complete. (Fig 7)
7. The catch can should be checked occasionally. The sight glass can be viewed from the engine bay using a flash light. To drain catch can turn the ball valve handle vertical, use a small cup to catch the contents.

Questions, comments, or concerns? Email [tech@racerxfabrication.com](mailto:tech@racerxfabrication.com).



