



## Toyota MR2 Battery Tie Down

91-95 Toyota MR2, applicable for Gen 2 and Gen 3

**Install time:** 5-10 minutes

### **In the Box:**

- (1) MR2 battery tie down
- (1) Tie down adapter
- (1) M6 stainless steel button head
- (1) 1/4" washer
- (1) 1/4"-20 clinching stud
- (1) 1/4"-20 flange nut

### **Tools:**

- 4mm allen key
- Socket driver
- 10mm socket
- 11mm socket

### **Instructions:**

1. Install or check the OEM battery hook. (Fig 1)
2. Install but do not tighten the battery tie down adapter. (Fig 2)
3. Using a 10mm socket tighten the bolt at the back of the battery. Do not over tighten bolt. (Fig 3)
4. Install washer and insert clinching stud through the bottom of the adapter. Thread on fastener to retain stud. (Fig 3)
5. Tighten adapter using a 4mm Allen key. Finally, tighten nut holding clinching stud with an 11mm socket. Do not over tighten fasteners. (Fig 4)

Questions, comments, or concerns? Email [tech@racerxfabrication.com](mailto:tech@racerxfabrication.com).

