

MR2 Shifter Cable Bushing Spacers Installation Guide

Install time: 1 hour

Instructions:

- 1. Follow initial preparation instructions for shifter cable bushing kit if you have not installed the kit yet. If you have installed the kit, remove the kit.
- 2. You should now have both shifter cables removed from their posts and removed the shifter bearings.
- 3. Install shifter cable bushing spacer on upper and lower cable post as shown in figure. The shorter spacer is installed on the top cable post, the longer spacer is installed on the lower cable post. (Fig 1)
- 4. Install shifter cable bearing (from shifter cable bushing kit) as shown in figure. (Fig 2)
- 5. Attach shifter cables to bearings. (Fig 3)
- 6. Install cotter pin to secure shifter cables. The lower cable should have the cotter pin installed facing downward. (Fig 4)
- 7. Installation complete.

Questions, comments, or concerns? Email tech@racerxfabrication.com.











