



# Toyota MR2 Shifter Surround Kit

**Install time:** 15 - 30 minutes

**Tools:**

- 4mm allen key

**Instructions:**

1. Remove OEM shift knob, shift boot and shifter surround. Install (4) clip retaining nuts. (Fig 1)
2. Install retaining plate. (Fig 2)
3. Install (2) grommets. (Fig 3)
4. Install shift boot and cover plate. Thread in (4) M6 allen head bolts, but do not tighten. Adjust shift boot to prevent bunching. Tip: Shift boot may need trimming to prevent overlap. (Fig 4)
5. Install shift knob, do not over tighten. Tighten M6 allen head bolts using a 4mm allen key. Assembly is finished, enjoy your new shifter surround kit. (Fig 5)

Questions, comments, or concerns? Email [tech@racerxfabrication.com](mailto:tech@racerxfabrication.com).

