



Chevy Sonic Catch Can

Install Time: 30 minutes to 1 hour

In the Box:

- (1) Assembled catch can
- (2) O-ring boss fittings
- (2) Oil resistant hoses
- (2) M8 bolts and washers
- (1) Catch can mount

Tools:

- 11mm wrench
- 13mm wrench
- Needle nose pliers
- Exacto knife
- Trim removal tool

Instructions:

1. Start by installing the catch can mounting bracket. The mounting bracket will be located on the passenger side strut tower. Remove the plastic wire guide with the trim removal tool. (Figure 1)
2. Place the bracket on the stud where the plastic wire guide was removed. Then using needle nose pliers hold the weld nut as pictured. You will guide the weld nut into position. Then place the bolt through the mounting bracket and thread into weld nut behind structural plate on strut tower. (Figure 2, 3 & 4)
3. Tighten the bolt using an 11mm wrench. Then mount the catch can with the (2) M8 bolts, loc washers, and flat washers. Finally tighten bolts with 13mm wrench. (Figure 5)
4. Route hoses to intake manifold and air intake. The bottom fitting should be routed to the intake manifold. The top fitting should be routed to the air intake. (Figure 6)
5. If you are using the OEM intake manifold and OEM turbo you will need to cut the plastic hose off of the fittings. Then use the provided hose in the kit and route to the appropriate fitting on the catch can. (Figure 7)
6. Installation is complete, start vehicle and make sure there are no air leaks. We recommend to check and drain your catch can every oil change (3000 miles).

Questions, comments, or concerns? Email tech@racerxfabrication.com.



